




COURBES PRESSION MAXIMUM EURAC L100

MAXIMUM PRESSURE CURVES FOR EURAC L100

Pression maximum
de service tuyauterie libre
Maximum working pressure
with free-hanging pipes



Ø	L100
38,1	
40	
45	
50/50,8	
54	
55	
60/60,3	
63,5	
65	
70	
75	
76,1	
80	
82	
84	
85	
88,90	
95	
100	
101,6	
104	
105	
108	
114,3	

En stock - On stock


Sur commande - On order



COURBES PRESSION MAXIMUM EURAC M150 MAXIMUM PRESSURE CURVES FOR EURAC AND M150



Pression maximum
de service tuyauterie libre
Maximum working pressure
with free-hanging pipes



Ø	L150
38,1	
40	
45	
50/50,8	
54	
55	
60/60,3	
63,5	
65	
70	
75	
76,1	
80	
82	
84	
85	
88,90	
95	
100	
101,6	
104	
105	
108	
114,3	

En stock - On stock

Sur commande - On order




COURBES PRESSION MAXIMUM EURAC H100, H150 ET H200

MAXIMUM PRESSURE CURVES FOR EURAC H100, H150 AND H200

Pression maximum
de service tuyauterie libre
Maximum working pressure
with free-hanging pipes



Pression maximum
de service tuyauterie bloquée
Maximum working pressure
with clamped pipes



Ø	L100	L150	L200
38,1			
40			
45			
48,3			
50/50,8			
54			
55			
60/60,3			
63,5			
65			
70			
75			
76,1			
80			
82			
84			
85			
88,9			
90			
95			
100			
101,6			
104			
105			
108			
114,3			
125			
127			
129			
133			
139,7			
145			
152,4			
154			
155			
159			
168,3			
219,1			

En stock - On stock


Sur commande - On order



COURBES PRESSION MAXIMUM EURAC HX200, HX250 ET HX300

MAXIMUM PRESSURE CURVES FOR EURAC HX200, HX250 AND HX300

Pression maximum
de service tuyauterie libre
Maximum working pressure
with free-hanging pipes



Ø	L200	L250	L300
200			
203,2			
219,1			
244,5			
254			
273			
323,9			
355,6			

En stock - On stock

Sur commande - On order